



Delivery Cap Set Up & Removal



STEP 1

Remove shipping cap from the product by twisting off.



STEP 2

Position delivery cap on to the product and push down firmly in the center.




STEP 3

While pushing down, screw the cap tight. Position the barb towards its connection.



STEP 4

TO REMOVE: Unscrew white ring and move side to side to release.



CAPS

There are two different delivery caps available for use. The instructions for set up are the same for both caps.

Angled Barb Connection Cap SKU 5722491

Straight Barb Connection Cap SKU 6081606