



microTECH™ CONCENTRATES



DELIMER

FEATURES

- Safer Choice (DfE) recognized
- Non-foaming
- Designed for regular use
- Non-abrasive
- Concentrated acid formula

BENEFITS

- Removes lime fast and efficiently
- Excellent for deliming dishmachines
- Extends life of equipment
- Won't harm surfaces

RECOMMENDED USES

For removing lime from institutional equipment surfaces.

SPECIFICATIONS

Color : Green
Scent/Odor : None added
Character : Clear, non-viscous liquid
Foam : Non-foamer

pH use dilution : 2.0-3.0
Phosphorus content : 0.0%
Approvals : cRc, Safer Choice (DfE)

IMPORTANT

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is provided with each container shipped. It is also available on our website or from the distributor.

PRODUCT DIRECTIONS

EQUIPMENT TO USE

Jug or pail pump, abrasive pad or stiff brush.

DIRECTIONS TO USE

Do not use on aluminum. Use this product at 1-2 ounces to 1 gallon of water for general lime control.

INITIAL TREATMENT: Use 3-4 ounces per gallon of water. Allow areas of heavy deposits to soak for several minutes, then brush surface.

DISHMACHINE:

1. Drain, flush and clean out machine. Never add lime solvent to dishmachine containing warewashing detergent.
2. Close drain valve, fill tank(s) with hot water.
3. Add lime solvent at 5-6 ounces for each gallon of water.
4. Turn on pumps until lime can be brushed or flushed away.
5. Drain tank and flush.

DO NOT LET DELIMER SOLUTION REMAIN IN UNATTENDED DISH MACHINE.

PACKAGING

This product is available in 4/1 gallon cases (5502721).



epa.gov/dfesaferchoice

