

Shurguard HP RTU Wipes

This product is a one step disinfectant cleaner and deodorant towelette designed for general cleaning, disinfecting, and deodorizing of hard non-porous environmental surfaces. Cleans and disinfects hard non-porous surfaces in any room, any time. For everyday use on hard non-porous surfaces in hospitals and health care settings. Formulated with patented hydrogen peroxide technology and is a great on-the-go disinfectant. Pre-moistened wipes that disinfects for a deep down clean everyday, in every room. Do not use on glasses, dishes and utensils. Not recommended for use on brass, copper or marble.

Specifications

Color	Colorless wipe
Scent	Cherry
Character	Clear, non-viscous liquid
Foam	Low
pH Use Dilution	2.2 - 3.2
Phosphorus Content	0.1%
Approvals	N/A
Registrations	EPA

Pack Sizes

101104759	6/60 count wipes
101104758	4/160 count wipes



Directions For Use

For Use as a One-Step Cleaner/Disinfectant: 1. Pre-clean visibly soiled areas. 2. Pull towelette from dispenser and wipe hard, non-porous environmental surfaces. 3. All surfaces must remain visibly wet for 1 minute. Use a 5 minute contact time for Tuberculosis. Use a 3 minute contact time for fungi and a 5 minute contact time for Candida auris. 4. Allow to air dry or rinse with potable water if necessary. Note: All food contact surfaces must be rinsed with potable water. Do not use on glassware, utensils, or dishes.

For Use as Daily Bathroom, Restroom, Shower Room, and Locker Room Cleaner/Disinfectant: 1. Pre-clean visibly soiled areas. 2. Pull towelette from dispenser and wipe hard, non-porous environmental surfaces. 3. To disinfect, all surfaces must remain wet for 1 minute. Use a 5 minute contact time for Tuberculosis. Use a 3 minute contact time for fungi and 5 minute contact time for Candida auris. 4. Wipe surfaces dry or rinse or allow to air dry.

For use as a Non-Food Contact Sanitizer: 1. Pre-clean visibly soiled areas. 2. Pull towelette from dispenser and wipe hard, non-porous environmental surfaces. 3. Allow the surface to remain wet for 30 seconds. 4. Wipe surfaces dry or rinse, or allow to air dry. 5. Change towelette after each use. Dispenser Directions: Remove lid to expose dispenser and seal film. Remove film. Pull wipe up from center of roll and thread through lid. Replace lid. Pull wipe at angle towards you to dispense one wipe at a time. Separate wipe at perforation. When finished, close lid to retain moisture.

Safety Reminder

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is available on our website at www.uschemical.com and is also available by scanning the QR code on the label.

